Stick Mixer

Model: RS1933SM

INSTRUCTION MANUAL

SAVE THESE INSTRUCTIONS

Dear Valued Customer

Thank you for choosing to purchase this appliance, we appreciate your business. We have provided a product, which is value for money.

TECHNICAL INFORMATION

Please make sure that your house installation voltage corresponds to the voltage marked on the unit.

Mains supply:	230-240V ~ 50 Hz – AC only
Output:	120 Watts

FOR YOUR SAFETY

Carefully read these instructions before using your appliance for the first time.

Do not immerse in water or other liquids. Do not use near washbasin or sinks. Ensure that the appliance does not get wet and do not use it with wet hands.

Keep out of reach of children. This appliance is not intended for use by young children or infirm persons without supervision. **Young children must be supervised to ensure that they do not play with the appliance.**

Use this appliance only for its intended use. This appliance is intended for household use only and not for commercial or industrial use.

The appliance should not be used outdoors, placed near a hot gas or electrical burner or placed in a heated oven.

Do not let cord hang over edge of table or counter.

Do not leave this appliance unattended when connected to the mains supply.

Use only genuine attachments supplied by an authorised Service-Dealer.

If appliance is to be used by a third party, please supply the instruction manual with it.

No liability can be accepted for any damage caused by non-compliance with these instructions or any other improper use or mishandling.

FOR ELECTRICAL SAFETY

- This appliance must be connected to a 230-240 V AC 50Hz mains supply.
- An appliance should never be left unattended when plugged in.
- An appliance dropped or damaged should not be used until examined by a service engineer.
- Do not permit the power cord to come in contact with hot objects. Please ask a service engineer to replace a worn or damaged power cord immediately with an approved lead of the same size and type.
- Do not attempt to service this appliance yourself. Refer servicing to qualified service personal.

This unit has been permanently lubricated at the factory and requires no further lubrication.

OPERATING INSTRUCTIONS

After unpacking the stick mixer wipe with a damp cloth or towel and dry with a dry cloth or towel.

Plug the stick mixer into an AC power outlet.

Avoid contact with moving parts. Keep hands, hair, clothing, as well as spatulas and other utensils away from blades during operation to reduce risk of injury to you and/or damage to the appliance.

This appliance can be used to chop small solid ingredients or to mix liquids. Cut larger ingredients into smaller pieces before placing into mixing bowl or container. If chopping fruits or vegetables, use a container with tall sides.

Do not place unnecessary strain on the motor by mixing mixtures, that does not allow the blades to revolve freely

Place mixing blade into ingredients and turn on. Hold the stick mixer firmly. The mixer will turn off once switch is released.

During mixing, occasionally use a spatula (not supplied) to scrape mixture from the sides of the bowl to ensure that all the ingredients are thoroughly and evenly mixed.

Note: Short-term operation. This appliance is designed for short-term operation only and must not be continuously operated for periods of time in excess of 1 minute. If operated continuously for up to 1 minute, switch the appliance off for a period of 5 minutes and allow it to cool down completely before further operation.

HOW TO CLEAN YOUR STICK MIXER

After use and before cleaning always remove plug from the mains supply.

To clean the outer surface of the Stick Mixer, use a soft damp cloth and dry it afterwards with a dry towel.

Do not immerse the mixer body or the mixing arm in water.

Guarantee Card

This product is guaranteed against faulty materials and workmanship for a period of twelve months from the date of purchase. The obligation to the purchaser under this warranty is limited to servicing the unit and replacing defective parts when the product is returned freight prepaid to the retailer. This warranty becomes void if the product has been tampered with, damaged by accident, damaged in any other way by improper use or has been purchased second hand. All production orders have quality inspections. In the unlikely event of a deficiency, please contact the retailer from whom this product was purchased.

WARRANTY FOR APPLIANCES USED COMMERCIALLY LIMITED TO 90 DAYS

Type of Appliance: _____

Model No.: _____ Purchase Date: _____

Product Purchased From: _____

_____

Your Name: _____

Address: _____

_____ Phone Number: _____

IMPORTANT!

Please retain this warranty card along with your purchase receipt. Please do not post to the retailer or importer. If service is required, both of these documents are to be returned with the appliance to your retailer, otherwise a fee may be charged.